

Broil King



Broil King CROWN 440
982163



Broil King CROWN 490
982183





Broil King CROWN 440S
982563





Broil King CROWN 490S
982583


1

(8) 




2

(4)  (4) 





3





4

(8)





5

(4) 




6


(4) 




7





8

(2) 






9

(4) 









10

(4)  (4) 




11

(2)






12

(1)




(1)




13




14




15

(4) 




16




17


(1)




1






2








3





4




18




19



20



21



KEY #	ITEM #	DESCRIPTION	982163	982183	982583	KEY #	ITEM #	DESCRIPTION	982163	982183	982583
1	56104-831	LID - SIDE PANEL - LEFT	1	1	1	80	53104-11	SIDE SHELF	1	1	1
2	56104-811	LID - SIDE PANEL - RIGHT	1	1	1	81	53104-13	SIDE SHELF	1	1	1
3	56315-801	LID - OUTER PANEL	1	1	1	83	53184-118	LID SHELF - SIDE BURNER	1	1	1
4	56245-301	LID - INNER PANEL	1	1	•	85	53184-138	SIDE SHELF - END CAP	1	1	1
7	56245-304	LID - INNER PANEL	•	•	1	86	10390-E10D	SIDE SHELF - END CAP	1	•	•
8	24005-12A	HANDLE	1	1	1	87	10390-E10E	SIDE BURNER	1	1	•
9	54009-936	HANDLE BEZEL	2	2	2	88	10390-E10NGE	SIDE BURNER - BODY	•	•	•
10	10081-BK630	NAMEPLATE	1	1	1	89	53004-271	SIDE BURNER - COVER	1	1	1
11	10571-6	HEAT INDICATOR	1	1	1	90	53000-251	SIDE BURNER GRID	1	1	1
12	52114-131R	PANEL - SIDE UPPER - LEFT	1	1	1	92	63139-981	SIDE BURNER GRID	1	1	1
15	52114-111R	PANEL - SIDE UPPER - RIGHT	1	1	1	93	10342-T21	SIDE BURNER ELECTRODE	1	1	1
17	56005-001P	FIREBOX	1	1	1	94	53404-114	SIDE SHELF FRONT	2	2	2
18	27245-904	GREASE SHIELD	1	1	1	95	23030-611	SIDE SHELF - BRACKET - RIGHT	1	1	1
19	52065-91	HEAT SHIELD - FRONT	1	1	1	100	23030-631	SIDE SHELF - BRACKET - LEFT	1	1	1
22	52045-92	HEAT SHIELD - REAR	1	1	1	108	Y-12220	GROMMET	1	•	•
23	52305-121	PANEL - REAR	1	1	1	110	10693-099	REAR BURNER ORIFICE	•	•	•
25	52315-151	PANEL - HOOD	1	1	1	111	10693-104	REAR BURNER ORIFICE	•	•	•
26	52904-144D	BURNER - MAIN	•	•	•	112	10693-161	REAR BURNER ORIFICE	•	•	•
27	52904-144E	BURNER - MAIN	4	4	4	115	S15271	HANDLE	•	•	•
28	52904-144NGE	BURNER - MAIN	•	•	•	116	S15270	BALANCE	•	•	•
29	52225-024	COLLECTOR BOX - FRONT LOWER	1	1	1	117	S15299	WASHER	•	•	•
30	52215-024	COLLECTOR BOX - FRONT UPPER	1	1	1	118	S15263	WASHER	•	•	•
33	52015-304	CONTROL COVER	1	1	1	119	S15259	BUSHING	•	•	•
34	52015-244	CONTROL ASSEMBLY	1	1	1	120	S15259	ROTISSERIE ROD	•	•	•
35	59005-073	CONTROL ASSEMBLY	•	•	•	121	S15259	4 PRONG FORK	•	•	•
36	59005-035	CONTROL ASSEMBLY	1	1	1	122	57039-901	ROTISSERIE BRACKET	•	•	•
38	S13470-073	HOSE - SIDE BURNER	1	1	1	129	S21123	SCREW - #8 X 1/2	12	12	12
39	S13470-079	HOSE - SIDE BURNER	1	1	1	130	Y-12835	SCREW - #8 X 1/4	2	2	2
40	27905-354	BURNER - ROTISSERIE	•	•	•	131	S21125	SCREW - #8 X 3/8	20	20	20
41	S15508	ELECTRODE	•	•	•	132	S21124	SCREW - #8 X 1/2	13	13	13
42	50809-957	TUBE - REAR BURNER ASSEMBLY	1	1	1	133	Y-12646	SCREW - #8 X 1/2	10	10	10
43	Y-11990	NUT HEX	•	•	•	134	Y-29304	SCREW - #10-24 X 3/8	30	30	30
44	22002-268	CONTROL BEZEL	4	4	4	135	S35094	SCREW - #10-24 X 5/8	1	1	1
45a	22001-168	CONTROL BEZEL	1	2	2	136	Y-29310	SCREW - #10-24 X 3/4	8	8	8
46	10472-K431	CONTROL KNOB	4	4	4	137	S35095	SCREW - #10-24 X 5/8	•	•	•
47	10472-K231	CONTROL KNOB	4	4	4	140	Y-12865	SCREW - 1/4-20 X 1/2	60	60	60
48	10342-247	ELECTRONIC IGNITOR	1	2	2	142	Y-12860	SCREW - 1/4-20 X 1	2	2	2
49	10342-246	ELECTRONIC IGNITOR	1	1	1	145	Y-11546	SCREW - SHOULDER 1/4-20 X 5/8	6	6	6
50	10342-E13	ELECTRODE	1	•	•	150	Y-29307	NUT - #10-24	2	2	2
51	52209-404	FLAV-R-WAVE®	2	2	2	151	Y-11793	NUT - 1/4-20	2	2	2
52	52007-281	GRID	4	4	4	153	Y-11795	NUT - 1/4-20 LOCK	2	2	2
53	52002-181	GRID	•	•	•	154	S21061	WING NUT #10	•	•	•
54	52005-991	GRID - WARMING RACK	2	2	2	160	Y-12857	WASHER	4	4	4
55	57055-902	GREASE TRAY	1	1	1	161	S21255	WASHER	2	2	2
56	21035-991	GREASE TRAY - RAIL	1	1	1	162	Y-12870	WASHER #10	2	2	2
57	52009-902	GREASE PAN	2	2	2	163	S21252	WASHER - M4	12	12	12
58	51175-131A	DOOR - LEFT HAND	1	1	1	169	S21233	CLIP	10	10	10
59	51175-134A	DOOR - RIGHT HAND	1	1	•	170	10240-23	HINGE PIN	2	2	2
60	51175-111A	DOOR - LEFT HAND	•	•	•	171	S21242	CLIP	4	4	4
61	51175-114A	DOOR - RIGHT HAND	1	1	1	172	Y-11544	BURNER SCREW	4	4	4
62	21071-13	DOOR HANDLE	1	1	1	173	10240-19	DOOR HINGE PIN - TOP	2	2	2
63	21070-13	HANDLE BEZEL	1	1	1	174	10240-20	DOOR HINGE PIN - BOTTOM	2	2	2
64	21109-905	CABINET - SIDE PANEL	2	2	2	175	Y-12127	DOOR CLIP	2	2	2
65	21305-925	CABINET - REAR PANEL	2	2	2	176	Y-12124	DOOR HINGE COVER	2	2	2
66	51615-235	CABINET - LOWER BASE	1	1	1	177	Y-12222	MAGNET	2	2	2
67	21039-301	TANK BRACKET	1	1	1	178	Y-12223	MAGNET - SNAP IN	2	2	2
68	51335-211	MAGNET BRACKET	1	1	1	180	Y-11235	LID BUMPER	4	4	4
69	57139-13	CONNECTION BRACKET	1	1	1	181	Y-11231	LID BUMPER - ROUND	2	2	2
70	51039-951	CASTER BRACKET	4	4	4	182	20005-000	MATCH LIGHT CHAIN	1	1	1
71	10892-23	CASTER	4	4	4	184	S21362	SPRING	•	•	•
72			4	4	4	185	S15245	MOTOR	•	•	•

